


EETI WinCE Touch Driver Installation Guide

Version: 3.1.4.4722

Operation System: Windows CE .6.0

Release Date:11-22-2010


1. Execute setup.exe, you will see the installation window.




2. Select Yes to continue the installation, or select No to cancel it.




- When installation successfully finish, you will see the window. Click Finish to close the installation window.




- Launch Visual Studio 2005 with Platform Builder WinCE6.0. Open your OSDesign which you want to install EETI Touch Driver.
- Select Project → Add Existing Subproject




6. Switch the folder to C:\EETICEDB\wince600



7. To add subprojects into your OSDesign, Choose the pbpxml file under different folder. (i.e. eeti232, eetiTool and eetiUSB)

[For USB Controller]Add **eeti TouchKit** and **eeti USB** subprojects into your OSDesign**[For RS232 Controller]**Add **eeti TouchKit** and **eeti RS232** subprojects into your OSDesign

8. After you add catalog items, you will find the subprojects inside your OSDesign.



9. Select Build → Make Run-Time Image to make the new image.

Notes:

- [For USB Controller] Select the UHCI or OHCI USB Host Controller driver into your platform which supported by the target device. Check the USB mouse can go well at the same port. Select the "Mouse" into your platform. This can be found in: Catalog Item Window, add "Core OS\CEBASE\Shell and User Interface\User Interface\Mouse"
- [For RS232 Controller] Select the COM port which touch device is using, please modify eeti232.reg

```
[HKEY_LOCAL_MACHINE\Drivers\BuiltIn\TouchKit1]
"Dll"="TouchKit.dll"
"Order"=dword:FF
"Prefix"="TKT"
"Index"=dword:00000001
"Context"=dword:1; →This is the COM Port setting.
```
- You can uninstall the catalog items in platform builder by execute setup.exe again.
- Note: If you wish to disable right button simulation, please do the following
 - 4-1: Modify eetiTool.reg: set RBSIZE = 0
 - 4-2: Remove AYGShell component in your OS Design. It locates under: Core OS -> CEBASE -> Shell and User Interface -> Shell -> AYGShell API Set

Driver Registry Settings:

Settings for eetiTool.reg:

[HKEY_LOCAL_MACHINE\Drivers\TouchKit]

Registry Key	Type	Description
RBSIZE	dword	set scale that will be treated as the same point, x-coordinate $\text{regin}(\text{pixel}) = (\text{RBSize} / 65535) * \text{x-coordinate resolution}$ set RBSize = 0 can disable right button
RBTIME	dword	set how long the same point pressed will treated as right button. The unit is 10^{-7} second.
FLAGS	dword	set 0x1 software filter enable set 0x3000 update EEPROM function enable set 0x100 to enable the check rotation function
SoundType	dword	SoundType = 0 is no sound SoundType = 1 is Beep in touch down. SoundType = 2 is Beep in lift off.
EdgeCompEn	dword	Edge compensation enable
EdgeCompUp	dword	Edge compensation upper bound parameter
EdgeCompDown	dword	Edge compensation lower bound parameter
EdgeCompLeft	dword	Edge compensation left bound parameter
EdgeCompRight	dword	Edge compensation right bound parameter
HalfVGA	dword	Touch mapping to screen parameter: HalfVGA=1: touch only on upper half of screen HalfVGA=2: touch only on lower half of screen HalfVGA=3: touch only on right half of screen HalfVGA=4: touch only on left half of screen
Baud	dword	RS232 baud rate setting: