

TOUCHKIT TOUCH DRIVER INSTALLATION GUIDE

Version: 1.23.1722


Operation System: Mac OSX 10.6 (64Bit Only) and later

Release Date: 03-22-2013

CONTENTS

1. Installation Procedure.....	2
2. TouchKit Utility Setting.....	4
3. Uninstall Driver.....	6


Note: Please make sure you are running under 64-bit kernel extension mode as following: Select Apple->About This Mac -> More Info and check your system setting. If you are not running 64-bit kernel and extensions mode, please install 32-bit driver.




1. Installation Procedure

Please unzip the driver package and launch TouchKit Installation procedure.

1.1 Please unzip the driver package and launch TouchKit Installation procedure.




1.2 Select Install button to continue.



1.3 Select destination to install, than select Continue Installation.



1.4 When installation success, press Restart to restart your computer.




1.5 Restart Computer.

2. TouchKit Utility Setting


2.1 Launch TouchKit utility

You can launch TouchKit Utility via \Appliation\ TouchKit.app




2.2 Calibration


To launch 4 point calibration, press 4 pts Cal to execute the procedure.



To launch 25 points calibration, press Advance->25 pts Cal




- 2.3 We suggest that users enable TPMon Open at Login in TouchKit utility. TPMon will monitor display setting changes and notify touch driver. Users use dual monitor display must enable TPMon.



3. Uninstall Driver


3.1 Delete kernel extension file

Delete /System/Library/Extensions/CUSBInterface.kext



3.2 Delete TouchKit Utility

Delete /Applications/ TouchKit.app



3.3 Delete TPMon Utility

Delete /Applications/TPMon.app

